



Wood Repair **BATTERY** Kit

for Knot Filler



This professional Wood Repair Kit comes with a Battery Gun perfect for Knot Filler application. The Battery Gun comes with a 100W 2.0Ah Lithium-Ion Battery (5.0Ah battery available on request). The big advantage of this Wood Repair kit is the freedom of movement which the cord-free battery gun allows you. It gives you perfect conditions for easy repair of knots, cracks etc. The Wood Repair BATTERY Kit is a complete repair kit with the most important tools for Knot Filler repairs!




- 1x Case
- 1x BCD 540 Knot Filler Gun
- 1x Lithium-Ion 2.0Ah battery (5.0Ah option by request)
- 1x Charger for Lithium-Ion Battery
- 1x Bag of Knot Filler Walnut (9 sticks of 300 mm)
- 1x Cooling iron w. handle 80 x 180 mm
- 1x Cutting tool 50 mm
- 1x Knot Filler color chart, print
- 1x Sanding paper

Instruction:


- 1) Apply a Knot Filler stick and turn on the gun
- 2) Shoot the Knot Filler into the knot/crack when the gun is warm and ready
- 3) Place a cooling iron/brick on the top of the repair. Do it quickly after filling for the best result.
- 4) Cut off excess Knot Filler with the cutting tool
- 5) Sand the repair and it is ready for after treatment
- 5) Use the aftertreatment you want - e.g. oil, lacquer, stain, paint etc.



Fill




Cool



Cut



Sand



After treat

BCD 540 Battery Gun

Professional and robust Knot Filler Gun with 100W 2.0Ah Lithium-Ion battery. A fully charged battery gives you an operating time on approx. 100-120 min. The BCD 540 Battery Gun comes as a complete set with a gun, battery and charger. Possibility for 5.0Ah battery on request.

