WOOD REPAIR

BCD 540 Battery Gun

Handling & maintenance



Technical info

- Accepts Ø12mm sticks
- Cord-free
- Robust and reliable tool
- 100 watt gun w. Lithium-Ion battery 18V 2.0Ah
- 100-120 min. operating time on fully loaded battery
- Pre-adjusted temperature 170 °C
- Ergonomic, lightweight tool
- Quick pre-heating
- Compatible with both 2.0Ah and 5.0Ah batteries



The gun must be placed in a standing position.

Never place the heated tool on the side.

Never point the nozzle upwards .

Caution!

The hot nozzle can cause damage and/or burns. After use, allow the gun to cool down completely before storing it. Keep safely and out of reach of children.

Handling

Please note the following handling points

- ✓ Let the gun pre-heat for about 3-5 minutes
- ✓ Never pull a stick backwards from the gun!
- ✓ Never place the gun on the side and do not point upwards
- ✓ Use only recommended adhesives
- ✓ Keep the melting chamber free of dirt and dust
- ✓ Protect the device from moisture and liquids
- Check the battery status ocassionally

Stroke adjustor

Knot Filler outpus is easily adjusted by turning the screw on the back of the tool.



Battery status indicator

Press the battery

button to see status

o remaining battery

Ergonomic design Lightweight tool with anti slip grip. Designed for long-term use.



Claims

Important info regarding claims

When we dismantle a tool, we can always see what caused the malfunction. In 99% of the cases, one of the below mentioned points has occured - they are not valid reasons for a complaint. If you are convinced that none of the points have occured, we will gladly check the tool in our workshop.

The following errors are not valid reasons for complaint:

- The gun was placed on its side.
- The gun and nozzle were held upwards for too long.
- The gun was not heated enough before starting.
- A stick was pulled backwards from the gun.